BAM
Federal Institute for Materials Research and Testing

Unter den Eichen 87
12205 Berlin
Germany
Phone: +49 30 8104-0
E-mail: info@bam.de
Internet: www.bam.de

User manual

BAM List 2015

Requirements for tanks for the carriage of dangerous goods

22nd of June 2015

© 2015 Federal Institute for Materials Research and Testing (BAM)

Help of BAM List 2015

13th edition

Published 2015-06-22
Copyright © 2015 Federal Institute for Materials Research and Testing (BAM)

Abstract

BAM List 2015 - Requirements for tanks for the carriage of dangerous goods

The BAM List serves as basis for the BAM's substance-related prototype approvals for tank containers and portable tanks designed for the transport of dangerous goods. Since 2013 this applies also to prototype approvals for demountable tanks and fixed tanks (tank-vehicles). In addition, the list is used as a knowledge base for the approval of tank-wagons. Furthermore, it serves as a reference for the material related evaluation of other types of containments carrying dangerous goods.

Only those data of dangerous goods are incorporated that may be transported in tanks. Explosives of class 1 are with a few exceptions not included due to the special requirements. Radioactive materials of class 7 have been completely omitted.

The present document shall give you an easy access to use the BAM List.

Published by the Federal Institute for Materials Research and Testing (BAM)

Team BAM List
Division 3.1 Dangerous Goods Packaging, Division 3.2 Tanks for Dangerous Goods and Accidental Mechanics
Federal Institute for Materials Research and Testing (BAM)
Unter den Eichen 87, 12205 Berlin

Phone: +49 30 8104-1314
Fax: +49 30 8104-1317
E-Mail: bamliste@bam.de
Internet: en.bamliste.de

1. Installing and Uninstalling 1
1.1. Standalone application (single user) 1
1.1.1. Installing 1
1.1.1.1. System requirements 1
1.1.1.2. Step-by-step guide 1
1.1.1.3. Demo version 2
1.1.2. Uninstalling 3
1.2. Network application (multi user) 3
1.2.1. Installing 3
1.2.1.1. System requirements 3
1.2.1.2. Step-by-step guide 4
1.2.1.3. Demo version 4
1.2.2. Uninstalling 5
2. First steps 6
2.1. Substance lists by topics 6
2.1.1. Search for a UN record (e. g. butylene) 7
2.1.2. Search for a substance 9
2.1.3. Material resistance data 9
2.2. Create substance lists 11
3. Usage 14
3.1. Menu bar 14
3.1.1. Menu *File* 14
3.1.2. Menu *Language* 14
3.1.3. Menu *Help* 15
3.2. Tool bar 16
3.3. Status bar 16
3.4. Navigation tree 16
3.4.1. Substance lists by topics 16
3.4.2. Create substance lists 17
3.5. Main window 17
3.5.1. Substance lists by topics 18
3.5.1.1. Table view 18
3.5.1.1.1. Filter row 19
3.5.1.1.2. Table header 20
3.5.1.1.3. Table contents 21
3.5.1.1.4. Status row 22
3.5.1.2. Detail view 22
3.5.1.2.1. Classification 22
3.5.1.2.2. Containments 23
3.5.1.2.3. Material resistance 25
3.5.1.2.4. Physico-chemical properties 26
3.5.2. Create substance lists 27
3.5.2.1. Tanks 27
3.5.2.2. Bulk container 30
3.5.2.3. Bulk 31
3.5.2.4. Material resistance 32
3.5.2.5. Substance lists 33

1

Installing and Uninstalling

This chapter contains information on the installation of the application, the requirements of your computer and the removal of the BAM list. If you download the software BAM List from www.bamliste.de, you may choose between a local standalone application for one PC or a network application for multiple PCs or users.

The BAM List is written in the programming language JAVA. If you do not have already installed a version of JAVA on your Windows operating system, the BAM List brings an own Java Runtime Environment (JRE). These files are stored in the subdirectory "jre" in the installation directory of the BAM List. To execute the software BAM List JRE 1.7 or higher is required. In the installed subdirectory "jre" you find the current version of JRE 1.8_45. This JRE is not installed system-wide, but only used by the BAM List.

1.1. Standalone application (single user)

If the BAM List is needed for one user only, the installation of the standalone application is recommended.

1.1.1. Installing

Before the installation, please make sure that no version of BAM List 2015 is already installed on your system, otherwise the installation can not be performed. Uninstall the existing version at first prior the installation. Older versions of the BAM List, such as BAM List 2013, do not necessarily have to be uninstalled.

1.1.1.1. System requirements

To install the BAM-List, your system shall meet the following requirements:

- Windows operating system (7, 8, 8.1),
- Local hard drive with minimum 165 MB free hard disk space.

You also need

- Administration rights,
- Valid license key.

1.1.1.2. Step-by-step guide

After having purchased a valid license to use the BAM List, you will receive an e-mail containing a download link and a license key. Click on the download link and save the file "BL2015Setup.exe" on your hard disk. Now make sure that you have administration rights to perform the installation. Open the setup file with a double click and follow the instructions of the installation wizard:

BAM List 2015 Setup
Welcome to the BAM List 2015 Setup Wizard
This wizard will guide you through the installation of BAM List 2015.
It is recommended that you close all other applications before starting Setup. This will make it possible to update relevant system files without having to reboot your computer.
Click Next to continue.
Next >
Cancel

Figure 1.1. Installation wizard of BAM List 2015

1. At first a welcome screen appears. Click on "Next".
2. Read carefully the license agreement. Accept the license terms by clicking the checkbox and then click "Next".
3. Copy the license key from the e-mail and paste it into the text box of the installation wizard. Click on "Next".
4. Select the directory in which the BAM List shall be installed. The directory should be empty and not write-protected. By default the software is installed to "C:\Program Files\BAM List 2015\" or "C:\Program Files (x86)\BAM List 2015\". Once you have made your selection, click on "Next".
5. Next you will be asked in which start menu folder the shortcuts of the software should be placed. The default directory is "BAM List 2015". Click on "**Install**" to start the installation.
6. If you have successfully installed the BAM List, click "Next" to see the last page of the installation wizard.
7. Select the check marks, if you want to start the BAM List immediately and whether a shortcut on the desktop should be created. Then click "Finish" to complete the installation.

1.1.1.3. Demo version

The demo of BAM List is a fully featured version with a restricted number of dangerous goods in the data-

base. It offers you the opportunity to test the software for an unlimited period before purchasing a full license.

The demo version is available for free at www.bamliste.de. No license key is required for the installation.

1.1.2. Uninstalling

To remove the BAM List 2015 from your computer, you need administration rights. Please make sure that BAM List 2015 is not running on your PC to perform the uninstallation. Open the the overview of all installed programs in the Windows Control Panel and search for the entry "BAM List 2015" or "BAM List 2015 Demo" and click on "Remove" or "Uninstall". The uninstall wizard of the BAM List will be opened. It removes the entire application, the corresponding shortcuts on the start menu and on the desktop and the Windows registry entries.

Alternatively, you can go to your installation directory of the BAM List and start the uninstallation by performing a double-click on "uninstall.exe".

1.2. Network application (multi user)

The installation of the network application is recommended for companies which operate an intranet to provide the BAM List to several users.

1.2.1. Installing

The application is installed on the network drive (server). After the installation all users of the BAM List have to execute a setup file stored on the network drive to register the BAM List on the local system.

1.2.1.1. System requirements

The network drive shall meet the following requirements:

- Minimum 165 MB free hard disk space,
- Write access on the network share for unpacking the installation files to a freely selectable directory,
- Read access from Windows clients.

Further needed for the installation on the network:

- Administration rights,
- Valid license key.

Minimum requirements for the client PCs:

- Windows operating system (7, 8, 8.1),
- Minimum 1 MB free disk space.

1.2.1.2. Step-by-step guide

Server

After having purchased a valid license to use the BAM List, you will receive an e-mail containing a download link and a license key. Click on the download link and save the file "BL2015NSetup.exe" on your hard disk. Now make sure that you have administration rights to perform the installation. Open the setup file with a double click and follow the instructions of the installation wizard:

1. At first a welcome screen appears. Click on "Next".
2. Read carefully the license agreement. Accept the license terms by clicking the checkbox and then click "Next".
3. Copy the license key from the e-mail and paste it into the text box of the installation wizard. The input of the license key is only needed for the server installation. Click on "Next".
4. Select a directory on the network drive in which the BAM List shall be installed. The directory should be empty and not write-protected. Once you have made your selection, click on "**Install**" to start the installation.
5. If you have successfully installed the BAM List, click "Next" to see the last page of the installation wizard.
6. Select the checkbox "Register client for BAM List", if you want to start the client installation immediately. Then click "Finish" to complete the installation.

Client

To enable users to start BAM List they have to perform the client installation on their computers.

Open on the client the installation directory on the network drive and execute the file "register.exe" to register the client for the network version of BAM List. Follow the instructions of the installation wizard:

1. At first a welcome screen appears. Click on "Next".
2. Read carefully the license agreement. Confirm the acceptance of the license terms by clicking the checkbox and then click "Next".
3. Next you will be asked in which start menu folder the shortcuts of the software should be placed. The default directory is "BAM List Network Client 2015". Click on "**Install**" to start the installation and register the client.
4. If the installation was successful, click "Next" to see the last page of the installation wizard.
5. Select the check marks, if you want to start the BAM List immediately and whether a shortcut on the desktop should be created. Then click "Finish" to complete the client installation.

1.2.1.3. Demo version

The demo of BAM List is a fully featured version with a restricted number of dangerous goods in the database. It offers you the opportunity to test the software for an unlimited period before purchasing a license. Please check the functionality of the BAM List as a network application on your system, especially in virtual-

ized environments (eg. Citrix) if it works correctly. If there are any problems, please contact us [mailto:bamliste@bam.de].

The demo version is available for free at en.bamliste.de. For the installation no license key is required.

1.2.2. Uninstalling

To uninstall all client links, click on the file "unregister.exe" on every client PC. This removes all shortcuts in the Windows start menu, on the desktop and in the Windows registry entries.

After uninstalling all clients, delete the directory on the network drive to uninstall the BAM List from the network drive.

2

First steps

If you like to get started using the BAM List without reading through the entire user's guide, use this first steps section to learn about the essential functions of the software.

The BAM List is divided into two main areas:

- "Substance lists by topics", to search for detailed information of dangerous goods and
- "Create substance lists", to create lists of substances, which include only substances for the transport in certain tanks, bulk containers or bulk, considering material resistance compatibility evaluations.

If you start the BAM List, a window opens on the screen that contains a menubar, a toolbar, the information area consisting of the navigation tree, the main window and at last a statusbar.

In this section you learn how to use the navigation tree and the main window.

2.1. Substance lists by topics

If you start the BAM List using the shortcut in the windows start menu or at the desktop, a splash screen during initialization is displayed. While the window of the BAM List opens, all data is loaded from the database. The loading process is displayed in the status bar at the bottom left. When all data are loaded, the total number of loaded substances is displayed.

The left side of the application window contains the navigation tree, which is separated from the main window by a displacable vertical divider. After the start the root node "BAM List" in the navigation tree is selected and a graphic in the main window is displayed. (see figure below "BAM List after start")

Figure 2.1. BAM List after start

2.1.1. Search for a UN record (e. g. butylene)

Initially you choose which transport regulation shall be searched: land transport (ADR and RID) or sea transport (IMDG) or both. You find these items if you select the topic "Classification" in the navigation tree. Click on the selected regulation.

Enter the search term in the main window in the free space above the selected column, e. g. the UN no. or a part of the name of the UN record (UN name). The search is not case sensitive. It will give you all the corresponding results that contain the search term.



Figure 2.2. Substance lists by topics (classification, land transport)

In our example "butylene" ten entries were found which match with the search term for the UN name. In the column "BAM Name" you find the substance (or the preparation of a substance) to which the entry applies. If you move the horizontal scrollbar to the right, you find all other classification criteria (see figure below). You will notice that some items or parts thereof are highlighted. These marks show you the difference in land transport between ADR (road) and RID (rail), although these regulations are largely harmonized. Blue highlighted text applies only to RID. Green highlighted text applies only to ADR. In addition, each of the modes (ADR or RID) are also shown in brackets afterwards.



Figure 2.3. Highlighting of differences between ADR and RID

To select a substance entry click on the requested row. For a better overview the details of that entry (see detail view) are displayed below the table. All fields which are yellow highlighted are clickable for an explanation of the codes. An additional dialog window with the explanations will be opened. The dialog can be closed using the escape key "Esc".

If you press the keys "Ctrl+C", you can copy the data of the selected row to your system clipboard. So you can use the data easily in text documents using copy and paste.

For further information on containments, material resistance and the physico chemical properties click on the tabs below the detail view.

2.1.2. Search for a substance

If you do not know about the UN record you may search for a substance itself. Type in the search term in the field above the column "BAM name" or "Synonyms" and proceed as mentioned above.

2.1.3. Material resistance data

Click on the "Material resistance" tab to find information on construction materials which are suitable for the selected substance. A green plus sign indicates that the combination of construction material and filling is generally permitted. A red minus sign indicates that the combination is not permitted. A gray question mark is displayed if no data is available for this combination of material and filling.



Figure 2.4. Material resistance data

An additional text field is shown behind each material resistance rating of metals. It can show conditions, that must be strictly met. To obtain the description of the code, e. g. "EK1MN" for mild steel, click on the yellow highlighted text field. A dialog window with the explanations will be opened. The dialog can be closed again by using the escape button "Esc".


Material resistance (Conditions)
E
Free of impurities, except for necessary stabilizers
K1
Fully rust-free inner tank wall
M
Tanks are to be transported or intermediately stored in such a way that the mean temperature of the liquid measured across the tank is 30 °C maximum.
N
The tanks are to be pressured with 0.5 bar (over-pressure) using nitrogen or some other suitable dry gas. The over-pressure must be maintained until the tank is completely empty.

Figure 2.5. Explanation of material resistance conditions

For more information about the research in the substance lists by topics look in the chapter "Usage" at the explanations of the navigation tree and the main window.

2.2. Create substance lists

The previous chapter briefly explained how to do the research in the substance lists. Now you will see how you can create your own lists of substances for specified tanks or construction materials. These lists may be saved as PDF and printed as well.

Example: if you have a tank for solids having the tank code "S4AH". Additionally the tank is provided with a vacuum valve with a set pressure of 0.05 bar. The tank is made of unalloyed mild steel (with a normal test period) and is coated with polyamide.

To find out which substances may be transported by land with this tank, select the item "Tanks" below "Create substance lists" in the navigation tree. An input mask pops up, where you enter the before mentioned tank parameters. If you have entered all the information the input mask looks like in the figure below.



Figure 2.6. Enter tank parameters

Now click on the button "Create list" at the bottom of the window.


BAM List 2015
File Language Help
Export list to PDF...
Help
BAM List
Substance lists by topics
Create substance lists
Tanks
S4AH+VV (Comp. eval.)
Bulk containers
Bulk
Material resistance
UN No. CAS No. BAM No. BAM Name Synonyms Su... Class ... T... Special provisi...
1350 7704-34-9 763 Sulfur [lump or coa... Sulphur 4.1 III SGAV
1350 7704-34-9 3164 Sulfur [fine-grained... Flowers ... 4.1 III SGAV
1446 10022-3... 1106 Barium nitrate [solid] 5.1 II SGAN TU3
1477 13126-1... 11489 Rubidium nitrate 5.1 II SGAN TU3
1486 7757-79-1 1114 Potassium nitrate [... Saltpetre 5.1 III SGAV TU3
1498 7631-99-4 1118 Sodium nitrate [solid] Chile salt... 5.1 III SGAV TU3
1557 10103-6... 7361 Copper arsenate 6.1 II SGAH TU15, TE19 (ADR
1564 513-77-9 135 Barium carbonate 6.1 III SGAH TU15, TE19 (ADR
1564 10361-3... 1419 Barium chloride [an... 6.1 III SGAH TU15, TE19 (ADR
1564 21109-9... 4418 Barium sulfide [solid] Barium m... 6.1 III SGAH TU15, TE19 (ADR
1616 6080-56-4 151 Lead(II) acetate tri... Lead ace... 6.1 III SGAH TU15, TE19 (ADR
1616 301-04-2 2878 Lead(II) acetate [a... Lead ace... 6.1 III SGAH TU15, TE19 (ADR
1811 7789-29-9 3117 Potassium bifluorid... Potassiu... 8 II SGAN
1812 7789-23-3 3119 Potassium fluoride ... 6.1 III SGAH TU15, TE19 (ADR
1813 1310-58-3 535 Potassium hydroxid... Caustic p... 8 II SGAN
2680 1310-66-3 560 Lithium hydroxide ... 8 II SGAN
2680 1310-65-2 4758 Lithium hydroxide [... 8 II SGAN
2811 3646 Isocyanates [solid,... 6.1 III SGAH TU15, TE19 (ADR
2811 25321-2... 4549 Dichlorobenzene [is... 6.1 III SGAH TU15, TE19 (ADR
2811 6584 Isocyanates [solid,... 6.1 II SGAH TU15, TE19 (ADR
3077 92-52-4 4744 Diphenyl [solid] Biphenyl 9 III SGAV
3259 124-28-7 11348 N,N-Dimethyloctad... N,N-Dim... 8 II SGAN
3262 1305-62-0 9709 Calcium hydroxide ... Calcium ... 8 III SGAV
25 rows
Current search parameters
Tank code:
S4AH
Safety device:
Not available
Vacuum valve:
Available, with opening pressure >= 0.05 bar
Thermal insulation:
not active
Tank instruction:
not active
Metallic materials:
Mild steel (norm.)
Polymeric materials:
PA
Aggregate state:
not active
Maximum density:
not active
Maximum vapour pressure at 50 °C:
not active
Maximum vapour pressure at 65 °C:
not active
Hazard classes:
not active
7814 Substances loaded
Note: All special provisions are to be individually observed!
License granted to: BAM

Figure 2.7. Generated list of substances for tank code S4AH

As result a new item appers below "Tanks" in the navigations tree, that reflects the essential criteria of the previous input mask in its name. This node has been automatically selected and displays a substance list with suitable substances in the main window. On the right edge of the window you will find your specified search parameters.

Now you can restrict the result by filtering, sort it by columns and export it to a PDF file. For an export press the button "Export List as PDF..." in the toolbar or use the shortcut "Ctrl+E". The PDF export dialog will open, where you may modify the settings (file path, file name, title, description, font size etc). If you click on "Export" in this dialog, the substance list will be saved to a PDF file.

On the first page of the PDF file the document title and an optional description are displayed. In addition, the search parameters and filter parameters are specified, that the result may be reproduced. From the second page all substances are listed which apply to the provided search and filter parameters.



Tank list (25 rows)

BAM No.	UN No.	UN Name, *BAM Name*	Class	PG	Tank code	Special provisions ch. 4.3/6.8	Tank instruction	Special provisions ch. 4.2	Conditions
763	1350	SULPHUR, *Sulfur [lump or coarse-grained powder]*	4.1	III	SGAV		T1	TP33	A
3164	1350	SULPHUR, *Sulfur [fine-grained powder]*	4.1	III	SGAV		T1	TP33	A
1106	1446	BARIUM NITRATE, *Barium nitrate [solid]*	5.1	II	SGAN	TU3	T3	TP33	A
11489	1477	NITRATES, INORGANIC, N.O.S., *Rubidium nitrate*	5.1	II	SGAN	TU3	T3	TP33	A
1114	1486	POTASSIUM NITRATE, *Potassium nitrate [solid]*	5.1	III	SGAV	TU3	T1	TP33	T
1118	1498	SODIUM NITRATE, *Sodium nitrate [solid]*	5.1	III	SGAV	TU3	T1	TP33	A
7361	1557	ARSENIC COMPOUND, SOLID, N.O.S. [inorganic, including: Arsenates, n.o.s., Arsenites, n.o.s., and Arsenic sulphides, n.o.s.] (Land), ARSENIC COMPOUND, SOLID, N.O.S. [inorganic, including: Arsenates, n.o.s.; Arsenites, n.o.s.; and Arsenic sulphides, n.o.s.] (Sea), *Copper arsenate*	6.1	II	SGAH	TU15, ADR: TE19	T3	TP33	A
135	1564	BARIUM COMPOUND, N.O.S., *Barium carbonate*	6.1	III	SGAH	TU15, ADR: TE19	T1	TP33	A
1419	1564	BARIUM COMPOUND, N.O.S., *Barium chloride [anhydrous, solid]*	6.1	III	SGAH	TU15, ADR: TE19	T1	TP33	AN
4418	1564	BARIUM COMPOUND, N.O.S., *Barium sulfide [solid]*	6.1	III	SGAH	TU15, ADR: TE19	T1	TP33	A
151	1616	LEAD ACETATE, *Lead(II) acetate trihydrate [solid]*	6.1	III	SGAH	TU15, ADR:	T1	TP33	A

Figure 2.8. Exported PDF file

For more information about creating substance lists see chapter "Usage" for further explanation of the navigation tree and the main window.

3

Usage

This chapter describes the use of the application in detail. Start the application by clicking the shortcut on the start menu in Windows, on the desktop or in the installation directory.

The BAM List displays a navigation tree on the left. On the right hand side there is the main window, where your searched information are presented. You find the menu bar and the tool bar in the upper part and the status bar below the main window.

3.1. Menu bar

You may access additional functions of the BAM List through the menu bar, which may not be found in the navigation tree.

3.1.1. Menu *File*

Click on the "File" menu, to access the sub-menu items listed below.

Export list to PDF...
: This menu item is context sensitive and will only be activated when you have already created and selected a substance list in the navigation tree (see "Create substance lists"). By clicking on this menu item, or by pressing the key combination "Ctrl + E", you can export the substance list to a PDF file and save it. At first a corresponding dialog box opens in which you can make further adjustments.

Exit
: Click on the menu item "Exit" to close the BAM List. Generated lists of substances in the navigation tree are not automatically saved. Of course all substance lists that are already exported in PDF files are retained.

3.1.2. Menu *Language*

In the "Language" menu, you may change the language setting of the BAM List. Each user is able to select individual settings. From this alteration both the user interface (GUI) and the presented data/contents of the BAM List are affected. For the changes to take effect, you have to restart the application.

German
: Click on "German", then the entire application will be changed to German. If German already has been

selected, this action has no effect. Otherwise you are indicated in a dialog box, that the change is available only after restarting the BAM List.

English
: Click on "English", then the entire application will be changed to English. If English already has been selected, this action has no effect. Otherwise you are indicated in a dialog box, that the change is available only after restarting the BAM List.

3.1.3. Menu *Help*

The "Help" menu contains technical information and instructions for use of the BAM List.

Special provisions
: In the menu item "Special provisions" all texts from sections 4.2 in land transport and 4.3/6.8 in the land and sea transport are listed, which are relevant for tank containers. The menu item is divided into:

- TP - Portable tanks
- TU - Use
- TC - Construction
- TE - Equipment
- TA - Approval
- TT - Test
- TM - Marking

Material resistance
: Under this menu item you will find detailed information on the collection of material resistance data. The menu is further divided into:

- Fundamentals of material resistance evaluation,
- Compatibility evaluation of metallic tank materials,
- Compatibility evaluation of gasket, coating and lining materials and
- Compatibility conditions.

First steps
: With this quick start, you can jump directly to the chapter in which an example describes how you can work with the BAM List.

Help
: Click this menu item, if you want to open the complete help information. Alternatively you may access the help by pressing the key "F1". The help opens instantly and refers to that chapter which is related to the selected item in the navigation tree.

License
: This menu item displays your license information consisting of licensee (company, contact person) and license (licence type, number of users, license number, date of creation of the license).

Info
: Here you will find information about the version of the BAM List and the used software as well as contact options.

3.2. Tool bar

The tool bar contains commonly used functions from the menu bar for a quick access.

Figure 3.1. Tool bar

You find a context-sensitive button to export a self-generated list of substances in a PDF file (see also the corresponding menu item) and a button to access the help (see also the corresponding menu item).

3.3. Status bar

At the bottom of the main window of the BAM List there is a text line, which displays status information. It indicates which data during the startup of the BAM List have been successfully loaded from the database. After the loading of data it displays the total number of records/substances contained in the BAM List.

On the right of the status bar, the licensee of the BAM List is indicated. By clicking on the text a dialog box is opened in which the full license information (see also the corresponding menu item) is displayed.

3.4. Navigation tree

The navigation tree is always located at the left side of the window, to the right is the actual area to display the information. Both areas are separated by a narrow beam. If you slide the mouse over the bar between navigation tree and main window, an icon with a double arrow to the left and to the right appears to move the bar horizontally. This allows you to provide either the navigation tree or the main window more space to display.

If you have selected the top node "BAM List" in the navigation tree, you will see an information graphic in the main window, that contains information about the version of the BAM List and its publisher. You can also find our homepage on the internet www.bamliste.de [http://www.bam.de/en/service/publikationen/bam_liste.htm] and contact us directly by e-mail bamliste@bam.de [mailto:bamliste@bam.de].

3.4.1. Substance lists by topics

If you open the node "Substance lists by topcis" you will find all topics which are included in the BAM List:

- Classification,
- Containments,
- Material resistance and

- Physicochemical properties.

The mentioned topics, except "Physicochemical properties", are divided into further items, to make the search more comfortable. The topics of "Classification" and "Containments" are each split into the mode of transport:

- Land transport,
- Sea transport and
- Land and sea transport.

While in "Land transport" or "Sea transport" only the typical characteristics for the selected transport regulation are displayed, "Land and sea transport" contrasts the characteristics of both modes of transport.

The topic "Material resistance" is divided into:

- Metals and
- Polymers.

3.4.2. Create substance lists

With this function a substance list for a containment (tanks, bulk container, bulk) is created, which are allowed for transportation in that containment. Additionally you can create a substance list for construction materials or combinations of these, which are suited for such containments. These lists can be saved as PDF file and printed. Choose an item from the navigation tree for that:

- Tanks,
- Bulk container,
- Bulk or
- Material resistance.

Each substance list, which you have created, is added to the navigation tree under the selected topic. Such a node is generated with a short expressive name, that reflects the specified search criteria. The tree is able to display any number of nodes, so that you may create as many lists of substances as you like. If you want to remove a substance list from the navigation tree, select it and press the "Delete" key. A deleted substance list cannot be recovered. In this case re-enter your search criteria and create the substance list again.

3.5. Main window

The main window shows all information which are selected in the navigation tree on the left. It displays either concise explanations in text form, it prompts you to make your search settings or it lists the search result in a

table view.

3.5.1. Substance lists by topics

Once you have selected a node in the navigation tree, which has further items, you will see a text in the main window that roughly describes which data are shown in the respective nodes.

If you select a node which has no sub-items, the table view appears in the main window in the upper area and the detail view in the lower area. The horizontal divider between table and detail view may be moved to give either the table or the detail more space. Simply move the mouse on the divider so that the cursor changes to an upward and down double arrow. Hold down the left mouse button and drag the bar to the desired position.

Furthermore, the horizontal divider has two small arrows (triangles), which maximizes the view of one of these areas. Click on the up arrow so that the lower section with the detail view takes the entire place. If you click the down arrow only the table view is displayed.

3.5.1.1. Table view

The table view shows the data of individual substances. If the content of the table is not displayed completely on the screen, then the corresponding scroll bars are provided.

The table view consists of the following components from top to bottom:

- Filter row,
- Table header,
- Table contents and
- Status row.

chloride

ADR Status	RID Status	UN No.	UN Name	BAM No.	BAM Name	Sub...	Class	Clas...	Packin
●	●	1717	ACETYL CHLORIDE	11	Acetyl chloride	✓	3	FC	II
●	●	1037	ETHYL CHLORIDE	51	Ethyl chloride	✓	2	2F	
●	●	1726	ALUMINIUM CHLORIDE, ANHYDROUS	92	Aluminium chloride [anhydro...	✓	8	C2	II
●	●	1107	AMYL CHLORIDE	116	n-Amyl chloride	✗	3	F1	II
●	●	1730	ANTIMONY PENTACHLORIDE, LIQUID	124	Antimony pentachloride [liqu...	✓	8	C1	II
●	●	1731	ANTIMONY PENTACHLORIDE SOLUTION	125	Antimony pentachloride [no...	✓	8	C1	II
●	●	1733	ANTIMONY TRICHLORIDE	127	Antimony trichloride [solid]	✓	8	C2	II
●	●	1560	ARSENIC TRICHLORIDE	133	Arsenic trichloride	✓	6.1	T4	I
●	●	1886	BENZYLIDENE CHLORIDE	137	Benzylidene chloride	✓	6.1	T1	II
●	●	2225	BENZENESULPHONYL CHLORIDE	140	Benzenesulfonyl chloride	✓	8	C3	III
●	●	1736	BENZOYL CHLORIDE	144	Benzoyl chloride	✓	8	C3	II
●	●	2670	CYANURIC CHLORIDE, MOLTEN	152	Cyanuric chloride [molten]	✗	8	C4	II
●	●	2395	ISOBUTYRYL CHLORIDE	217	Isobutyryl chloride	✓	3	FC	II

290 rows (filtered by BAM Name)

Figure 3.2. Table view for topic classification (land transport)

3.5.1.1.1. Filter row

Each column of the table has a separate field on top to enter filter criteria. Each of these fields has a small filter icon in the top right corner. If there is no filter, the filter icon is gray ( ). If filter criteria are set, the icon is activated and shown in green ( ). All column titles in which a filter is active are indicated in the status row.

If there are only certain filter criteria possible for a column (e. g. for packing group the values: I, II and III), a popup menu will be opened by left mouse click in the input field offering the predefined filter criteria for this column.

Example: the popup menu for the column "Class" with filter criteria as shown in the figure below. There are only values offered which lead to at least one hit, provided that only this column is filtered.



Figure 3.3. Filter popup menu of the column "Class" in land transport

As an additional feature the popup menu allows you to search for those substances with no value specified; that means the corresponding entry in the table is empty. Furthermore you may reset the filter of the current column or of all columns of the table by using the last two menu items. If you reset all filters, all records are displayed again. The reset cannot be undone, but you can re-enter your filter criteria in the corresponding columns as described.

If you don't want to use the default options of a popup menu, you can even enter the filter criteria in the search box instead. Close the opened popup menu by pressing the escape key "Esc" or double-click in the search field. Now the field gets the focus so that you can type in your search criteria.

Filtering the table is usually done by specifying regular expressions (excluded are the numeric columns in the topic physico-chemical properties). If you are not familiar with regular expressions, it is sufficient to enter the search text or parts of it. It is irrelevant whether you specify the term in uppercase or lowercase. As a result all the substances are displayed, in which the substring (e. g. "butane" for UN name) is contained, whether it is at the beginning, middle or end of the name. If you want to search only the substances, which start with "butane", enter a regular expression like "^butane". The sign "^" indicates the beginning of an expression.

In the topic physico-chemical properties you may search or filter the numeric columns by means of the following relations (see table below). The relation symbols are given in ascending order, as they would also be displayed in an ascending sorted column. In each numeric column only one relation can be specified, for example "<= 22.5". If an invalid input filter is given, for example with letters, the result list will always be empty.

Table 3.1. Relation symbols to filter numeric columns (physico-chemical properties)

relation	relation symbol
less than	<
less than or equal	<=
approximately equal	~
equal	not specified or =
greater than or equal	>=
greater than	>

If you use a left click in the filter box and no popup menu opens, just use the right mouse button to open a popup menu, which has a similar structure to the already mentioned above. As the number of features in some filter criteria (for example UN name) is not limited, a filter history is offered instead. Each entered filter criterion is added to the history of the filter column, so that you can quickly access the previous entries via a right mouse click again. The history filter holds up to 10 recent search values.

The filter history is offered especially for numeric columns (in the physico-chemical properties), but also in columns like the "UN Number", the "BAM Number", the "UN Name", "BAM Name", "Synonyms" and others. Similar column contents are combined in a single filter history, so that it doesn't matter whether you enter a filter criterion to the UN name, to the BAM name or synonyms, it always appears in all this filter histories.



Figure 3.4. Filter popup menu in the column "UN Name" with filter history

3.5.1.1.2. Table header

The table header contains all titles of the columns. Click on a column title in table header to see the values of the table in ascending order. A triangle lying on the ground side appears at top of the column name. Slide the mouse over the column title in the table header and a tool tip in the form "column name (sorted in ascending order)" is displayed. Click again on the same column name to sort the values in descending order. You will see a downward pointing triangle next to the column name. Slide the mouse over this column title and a tool tip in the form "column name (sorted in descending order)" is displayed. According to a third click in the same column all the values are back unsorted.

If you like to alter the width of a column, use the mouse and click on the line between two columns in the table header. When the mouse pointer changes to a horizontal double arrow you can move the boundary to the left or right.

It is also possible to customize the order of the columns. To do this, click on the corresponding column name, hold down the left mouse button and move the column left or right to the desired position.

Far right on the edge of the table header, just above the vertical scrollbar of the table contents, there is a fil-

ter icon. This is to hide the filter row completely and thus to make all substances or lines visible in the table without filtering. The filter icon allows a fast switching between the filtered and unfiltered state of the table.

3.5.1.1.3. Table contents

The table displays the data of one substance per line. Use the mouse and select a single row to display more information of this substance in the detail view.

If you use the right mouse button, you can view the filter popup menu of that column where the mouse is currently located. The functionality of the popup menu is described in the section filter row.

If you select a table row and user the key combination "Ctrl+C", you copy all the data of the table row into your system clipboard. The copied data includes the title and the value of each table column. This data can be pasted to other text documents.

```
Classification (Land transport)
ADR Status: Classified dangerous good
RID Status: Classified dangerous good
UN No.: 1935
UN Name: CYANIDE SOLUTION, N.O.S.
BAM No.: 279
BAM Name: Cyanide [solution, inorganic, highly toxic, n.o.s.]
Synonyms:
Substance in dangerous goods list: yes
Class: 6.1
Classification code: T4
Packing group: I
Hazard label: 6.1
Hazard number: 66
Environ. hazardous: yes
Special provisions: 274, 525
Source: BAM List 2015, www.bamliste.de
```

Figure 3.5. Copied data row for cyanide, classification (land transport)

If you select a substance in a topic (such as classification, land transport), the line with that substance will automatically be selected in all other topics which are listed in the navigation tree. However, if you have active filter criteria in another topic not all lines are displayed. This may have the effect that the row of the substance cannot be selected.

Furthermore, there is a special feature included in some columns that applies only to land transport: in some cases exist different values for the road (ADR) and rail (RID) transport or values for only one regulation. These values are highlighted in different colors. Values that apply only to ADR are highlighted green and specified with "(ADR)". Values that apply only to RID, are highlighted blue and marked with "(RID)".



UN No.	Tank ...	Special p...	Tank code	Special provisions ch. 4.3/6.8	Bulk container	Special provis...	Transport categor
3278	T11	TP2, TP27	L4BH	TU15, TE19 (ADR)			2
3278	T14	TP2, TP27	L10CH	TU14, TU15, TE21, TE19 (ADR), TU38, TE22 (RID)			1
3244	T3	TP33	SGAV		BK1, BK2	VC1, VC2, AP7	2
3066	T7	TP2, TP28	L4BN				2
3066	T7	TP2, TP28	L4BN				2
3066	T4	TP1, TP29	L4BN				3
3066	T4	TP1, TP29	L4BN				3
1903			L10BH	TU38, TE22 (RID)			1
1903			L4BN				3
3282	T14	TP2, TP27	L10CH	TU14, TU15, TE21, TE19 (ADR), TU38, TE22 (RID)			1
3282	T11	TP2, TP27	L4BH	TU15, TE19 (ADR)			2
3282	T7	TP1, TP28	L4BH	TU15, TE19 (ADR)			2
3467	T6	TP33	S10AH	TU14, TU15, TE21, TE19 (ADR)			1

7814 rows

Figure 3.6. Highlighting the differences in land transport (ADR, RID)

3.5.1.1.4. Status row

The status row indicates, how many rows the table contains. If there are filter criteria set in the filter row, the status row informs you about the column titles with active filters.

3.5.1.2. Detail view

The detail view is below the table view and is divided like the node "Substance lists by topics" in the navigation tree in the items "Classification", "Containments", "Material resistance" and "Physico-chemical properties". The individual items may be displayed by clicking the corresponding tab pages.

While subject-specific data is displayed by changing the tabs, the headline shows the "CAS Number", the "BAM Number", the "BAM Name" and "Synonyms" (if available) for clear identification of the substance. The text boxes including the BAM name or synonyms are additionally provided with a tooltip to display names which are too long for the field.

In every tab there are fields which are highlighted yellow and where the cursor changes when you hover the mouse over it. Click on these fields to open a dialog box. The dialog gives a description of the codes in that field. The explanation from the respective dangerous goods regulation is given. The opened dialog can be closed by pressing the escape key "Esc".

Advice: The CAS Registration Number is property of the American Chemocial Society and underlies the regulations of that organisation. The declaration through the BAM is for information only and without liability. It serves for the purpose to make the search more comfortable and the identification of a substance easier.

3.5.1.2.1. Classification

On the tab page "Classification" in the detail view land and sea transport are juxtaposed, so differences and similarities can be identified. The displayed identification and substance characteristics are listed in the following table.

Table 3.2. Identification and substance characteristics (classification)

characteristic	land transport	sea transport
UN Number	yes	yes
UN Name	yes	yes
Class	yes	yes
Classification code	yes	no
Packing group	yes	yes
Hazard number	yes	no
Hazard label or class + subrisks	yes	yes
Environmentally hazardous	yes	yes
MARPOL	no	yes
Special provisions	yes	yes
Status	yes	yes



Figure 3.7. Detail view of classification

3.5.1.2.2. Containments

On the tab page "Containments" in the detail view land and sea transport are also juxtaposed, but with the difference that many charactaristics only apply to the land transport and sometimes even just to road transport (see table below).

Table 3.3. Substance characteristics (containments)

characteristic	land transport	sea transport
Tank instruction	yes	yes

characteristic	land transport	sea transport
Special provisions ch. 4.2	yes	yes
Bulk container	yes	yes
Special provisions bulk	yes	no
Tank code	yes	no
Special provisions ch. 4.3/6.8	yes	no
Transport category	yes	no
Tank vehicle type	yes (ADR)	no
Tunnel code	yes (ADR)	no

The main characteristics for the transport of dangerous goods in tanks are the tank instruction, the tank code and the special provisions for each.

The tank instruction is an alphanumeric code, which is assigned to an instruction of a portable tank. This portable tank instruction meets the minimum requirements that shall be met the carriage of the concerned substance for an approval of this portable tank. If no instruction is given, the carriage in portable tanks is not permitted. Tank instructions consist of the letter "T" and a number which indicates the applicable minimum test pressure, the minimum shell thickness (in mm reference steel), the requirements for bottom openings and the pressure relief device.

The tank code is an alphanumeric code describing a ADR/RID tank type. This tank type corresponds to the minimum requirements that shall be met for the carriage of the involved substances in tanks according to 4.3/6.8 ADR/RID. If no code is specified, the transport in tanks is not permitted according to chapter 4.3/6.8. Specifying "(+)" after the tank code means that the alternative use of tanks is permitted only if this is specified in the certificate of type approval.



Figure 3.8. Detail view of containments

If you click on one of the yellow highlighted fields, a dialog window opens (see figure below), in which all of

the field codes are described. Click on the box with the tank code, to get the explanation of the individual components of the tank code described above.

If you need an overview of all existing special provisions according to chapter 4.2 or 4.3/6.8, you can find these in the menu bar under the issue "Special provisions".


Tank code (Land transport)
The following applies to ADR:
L
Type of tank:
Tank for substances in the liquid state (liquids or solids handed over for carriage in the molten state)
10
Calculation pressure:
Minimum calculation pressure: 10 bar (see 6.8.2.1.14)
C
Openings (see 6.8.2.2.2):
Tank with top-filling and discharge openings with only cleaning openings below the surface of the liquid
Class 2:
Tank with top filling or discharge openings with 3 closures with only cleaning openings below the surface of the liquid
H
Safety valves/devices:
Hermetically closed tank (see 1.2.1)
Class 2:
Hermetically closed tank, battery-vehicle or MEGC (see 1.2.1)
The following applies to RID:

Figure 3.9. Explanation of a tank code

3.5.1.2.3. Material resistance

The detail view of the material resistance data offers a full view of all contained metallic and polymeric materials in the BAM List with their compatibility evaluations and in the case of metals the potentially necessary conditions.

Each material is associated with one of the icons listed in the table below (plus, minus, question mark), provided that you have already selected a row in the table view. In the material resistance evaluation for metals there are two entries for a metal, namely with short (2.5/3 years) or normal (5/6 years) inspection period (see chapter 6.7 and 6.8 of the regulations for further explanations of the inspection period). If necessary the conditions are stated behind the icon. In this case the text field is yellow highlighted and contains e. g. the letter and number combination "AH2N". Click on this text field to open a dialog window, which describes the meaning of these condition codes.

All materials, whether metal or polymer, are provided with an explanatory tooltip. For example have the cursor over the text "CrNi (short.)" or "ACM" for a moment and the respective tooltip appears which explains the abbreviation, such as "austenitic chromium-nickel steel (test interval 2.5/3 years)" or "acrylate copolymers".

Table 3.4. Icons for the material resistance compatibility

icon	meaning
	compatible, if necessary subject to conditions
	not compatible
	no data available



Figure 3.10. Detail view of material resistance

3.5.1.2.4. Physico-chemical properties

The detail view of the physico-chemical properties shows the vapor pressure (at 50 °C and at 65 °C), the density, the melting point, the boiling point, the flash point and the ignition temperature. For each of these properties, there is a text box with the value followed by an optional remark. On the far right is a number in parentheses giving a reference to the source from which the data is originated. Click on this number to open a dialog window in which the source is described.

In addition, the physical state and the state of aggregation during transport are given.

Remark: The specified flash point usually refers a closed cup (c.c.) measurement, unless there is a note given that is explicitly indicating a open cup (o.c.) measurement.


Data for selected substance
CAS No.: 106-95-6
BAM No.: 79
BAM Name: Allyl bromide
Synonyms: 3-Bromo-1-propene, Bromoallylene, 3-Bromopropene, 3-Bromopropylene
Physico-chemical properties
Vapour pressure at 50 °C in mbar: 500 [1]
Vapour pressure at 65 °C in mbar: 853 [1]
Density at 20 °C in kg/l: 1.4 [33]
Melting point in °C: -119 [33]
Boiling point in °C: 70 [33]
Flash point in °C: -1 [33]
Ignition temperature in °C: 295 [33]
Aggregate state: liquid
Aggregate state (transport): liquid
Classification
Containments
Material resistance
Physico-chemical properties

Figure 3.11. Detail view of physico-chemical properties

3.5.2. Create substance lists

If you want to generate lists of substances, you can compile these for the topics tanks, bulk containers and material resistance based on your search and filter criteria. The created lists may also be saved as a PDF file and be printed.

To generate lists of substances user provided parameters/entries are necessary that will be explained in the following subsections. Only when you have made this mandatory entries, the button "Create list" will be enabled. If there are still missing entries, a warning will be displayed directly over the button in a text line.

3.5.2.1. Tanks

Do you have a tank, knowing its identification characteristics such as tank code or tank instruction, and want to determine which dangerous goods may be transported in the tank, so you may create lists of substances for tanks.

If you have selected the node "Tanks" in the navigation tree an input mask appears in the main window which prompts you to specify the requirements of the tanks and other search criteria (see figure below).



Figure 3.12. Create tank list (parameter input)

To generate a tank list, select first which regulations shall be applied. For a ADR/RID tank you may enter the tank code directly to the enabled text box or use the button "..." to compose a code (see "Compose tank code").

For a hermetically closed tank (tank code H) you may choose if the tank is equipped e. g. with a bursting disc. For each tank you can specify whether it is equipped with a vacuum valve, and which opening pressure it has, whether a flame trap is present or whether it is an explosion-pressure proof tank. Furthermore you may specify if the tank has a thermal insulation. The additional information have an impact on the resulting tank code (in the case of the vacuum valve) and the number of the substances contained in the generated substance list.


Compose tank code
1st Part: Tanktype
Tank for substances in solid (powdered or granular) state (S)
Tank for substances in liquid or molten state (L)
2nd Part: Calculation pressure
Minimum calculation pressure (G)
Calculation pressure in bar:
3rd Part: Openings
Bottom openings with 2 shut off devices (A)
Bottom openings with 3 shut off devices (B)
Top openings, below the liquid level only cleaning openings (C)
Top openings, not below the liquid level (D)
4th Part: Safety valve/device
Tank with ventilation device:
without flame trap or not explosion-pressure proof tank (V)
with flame trap or explosion-pressure proof tank (F)
Tank without ventilation device and not hermetically closed (N)
Hermetically closed tank (H)
Resulting tank code: not valid
Please input a valid pressure!
Cancel
Accept

Figure 3.13. Dialog "Compose tank code"

If you want to compose the tank code with the help of the dialog, you have to make one selection in each of the four areas (tank type, calculation pressure, openings and safety valve/device) to receive the tank code. You need to make sure that you supply an entry in the text field "Calculation pressure in bar" if you did not select the minimum calculation pressure (G). Enter the calculation pressure in the unit "bar", it is rounded in the resulting tank code over to the next lower level, which is determined according to the definition of tank code. For example if you specify a pressure of 7 bar, a resulting tank code for a pressure of 4 bar is adopted. If you didn't specify a calculation pressure or if it is invalid, you receive a note at the bottom of the dialog. The tank code can only be accepted if no errors are present and the input is complete.

To enter the tank instruction for a portable tank (UN tank) you need to select at least one mode of transport in the corresponding area. Thereafter, the selection list with the tank instructions T1 to T22 is enabled. If you already know which tank instruction you want to search for, simply choose the item in the selection list. Otherwise you have the option to open the dialog "Compose tank instruction" by clicking the button "...". Some Information, such as the test pressure and the shell thickness of the tank, are mandatory to determine the associated tank instruction. For each input the resulting tank instruction is tested on its validity and shown at the bottom of the dialog. The button to accept the tank instruction is only enabled, if the resulting tank instruction is valid.


Compose tank instruction
Test pressure of the tank
Value of test pressure in bar:
Shell thickness of the tank
Shell thickness of the tank (in mm reference steel):
Inputs for the minimum allowable shell thickness according chapter 6.7.2.4.2
Diameter of the tank:
<= 1,80 m
> 1,80 m
Powdered or granular solid substances of packing group II or III only
Additional protection against shell damage
Pressure relief devices of the tank
Normal safety valve
Safety valve with bursting disk
Bottom openings of the tank
2 shut off devices
3 shut off devices or top discharge with cleaning openings
No bottom openings
Resulting tank instruction: not valid
Please input a valid pressure and a valid shell thickness!
Cancel
Accept

Figure 3.14. Dialog "Compose tank instruction"

In addition to the mentioned input of the tank code and tank instruction you can also perform a material resistance compatibility evaluation and further restrict the results either by the aggregate state, the hazard classes and the maximum density. More information can be found in the section "Create substance lists - Material resistance".

3.5.2.2. Bulk container

If you want to know which substances may be transported in a specified bulk container type, you can create a corresponding list for bulk containers. First you have to choose whether the bulk container is used for land transport, sea transport or both. Then select the bulk container type: BK1, BK2 or BK3. The button "Create list" is now enabled. Click on the button to create the list.

Table 3.5. Bulk container types

bulk container type	land transport	sea transport
BK1 - Sheeted bulk container	allowed	allowed
BK2 - Closed bulk container	allowed	allowed
BK3 - Flexible bulk container	prohibited	allowed



Figure 3.15. Create bulk container list (parameter input)

In addition to specifying the mode of transport and the BK-code you may also perform a material resistance compatibility evaluation as well as restrict the result by the aggregate state, the hazard classes and the maximum density. More information can be found under the section "Create substance lists - Material resistance".

3.5.2.3. Bulk

You can create a substance list for bulk selecting the special provisions VC and AP. Because these provisions may have longer texts, there are links "Show text" to display the text. In the created substance lists are shown these special provisions and also the tank code and the tank instruction.



Figure 3.16. Create list for bulk (parameter input)

3.5.2.4. Material resistance

To ensure the compatibility of substances with specific metallic or polymeric materials, you can create a material resistance list with your search criteria. You have to select at least one polymeric material or a metal and a polymeric material. For metals you can also choose whether it has a shortened or normal inspection period. If you want to see an explanation of the abbreviation of a material in the form of a tooltip, let the mouse pointer rest for a moment about the corresponding abbreviation. After one or two seconds the tooltip is displayed.

When you have selected the desired materials and the button "Create List" is enabled, click on it and view the list of substances. However, you also have the option to restrict the result with further specifications, for example the physical state of the substances. Check the box for "Only following" and click the desired values in any combination of: liquid, solid or gaseous.

If you are only interested in substances with a certain maximum density, you can check the appropriate box and enter the maximum value. If you don't specify a maximum value, only substances appear in the result for which a value for the density is stored in the BAM List. You can do the same for the maximum vapour pressure at 50 °C and 65 °C. Finally, you also have the opportunity to generate a substance list which is restricted on certain classes of dangerous goods. Check the box "Only dangerous goods" and select the desired classes.

The functionalities of the material resistance compatibility evaluation and the additional search criteria are also available in the other areas (Tanks, Bulk container, Bulk) of "Create substance lists", with the only difference that you have to check the box "Perform material resistance evaluation" first. Then the component with selectable materials is displayed.



Figure 3.17. Create material resistance list (parameter input)

3.5.2.5. Substance lists

The generated substance lists are added to the navigation tree under the respective parent node independent of the subject area (tanks, bulk containers, bulk, material resistance). As a node name the specified search parameters are used in a shortened form.

For tanks, for example, the tank code is appended with an optional "VV" for an existing vacuum valve, with an optional "EX" if the vacuum valve is ex-proof and with an optional "TI" for the thermal insulation. If you have a tank instruction, a "L" for land transport, "S" for sea transport or "M" for multi-modal transportation (land and sea transport) is added to the beginning. If a material resistance evaluation is carried out, "(Comp. eval.)" is added to the end.

For bulk you will see "VC, AP" in the navigation three, if you entered no search parameters. If you selected some search parameters, they will be listed, for example "VC1, AP3".

For bulk containers, the BK-code is prefixed with an "L" for land transport, "S" for maritime transport or "M" for multi-modal transportation (land and sea transport). Is a material resistance compatibility evaluation carried out, a "(Comp. eval.)" is added.

For a material resistance list, the specified materials are displayed, first the metals then the polymers. The navigation tree might look like this (see figure below).



Figure 3.18. Navigation tree with created substance lists

Choose one of the nodes with the created substance lists, to see a table with the results in the middle of the window. Right on the edge you can see "Current search parameters". It is an overview of your specified search parameters. The result table offers you the same features as described in section "Table view ". The result can be subsequently filtered and sorted.

UN No.	CAS No.	BAM No.	BAM Name	Synonyms	Sub...	Class	Pa...	Tan...	Spec...	Tank...	Speci
2506	7803-63-6	104	Ammonium hydrogen sulfate ...	Ammonium bisulfate, ...	✓	8	II	SGAV		T3	TP33
1492	7727-21-1	256	Potassium persulfate [solid]	Potassium peroxidisul...	✓	5.1	III	SGAV	TU3	T1	TP33
2579	110-85-0	316	Piperazine [anhydrous, solid]	1,4-Diethylenediamin...	✓	8	III	SGAV		T1	TP33
2509	7646-93-7	532	Potassium hydrogen sulfate [...	Potassium bisulfate, ...	✓	8	II	SGAV		T3	TP33
1466	7782-61-8	556	Ferric nitrate nonahydrate [s...	Iron trinitrate nonah...	✓	5.1	III	SGAV	TU3	T1	TP33
1467	506-93-4	557	Guanidine nitrate [solid]		✓	5.1	III	SGAV	TU3	T1	TP33
2508	10241-05-1	635	Molybdenum pentachloride [s...		✓	8	III	SGAV		T1	TP33
1350	7704-34-9	763	Sulfur [lump or coarse-graine...	Sulphur	✓	4.1	III	SGAV		T1	TP33
1495	7775-09-9	653	Sodium chlorate [solid]		✓	5.1	II	SGAV	TU3	T3	TP33
1773	7705-08-0	418	Ferric(III) chloride [anhydrou...	Ferric perchloride, Ir...	✓	8	III	SGAV		T1	TP33
2280	124-09-4	483	Hexamethylenediamine [solid]	1,6-Diaminohexane, ...	✓	8	III	SGAV		T1	TP33
2865	10039-54-0	494	Bis(hydroxylammonium) sulfa...	Bis(hydroxylammoniu...	✓	8	III	SGAV		T1	TP33
1452	10137-74-3	1108	Calcium chlorate [anhydrous,...		✓	5.1	II	SGAV	TU3	T3	TP33
1485	3811-04-9	1113	Potassium chlorate [solid]		✓	5.1	II	SGAV	TU3	T3	TP33
1486	7757-79-1	1114	Potassium nitrate [solid]	Saltpetre	✓	5.1	III	SGAV	TU3	T1	TP33
1488	7758-09-0	1115	Potassium nitrite [solid]		✓	5.1	II	SGAV	TU3	T3	TP33
1493	7761-88-8	1117	Silver nitrate [solid]		✓	5.1	II	SGAV	TU3	T3	TP33
1498	7631-99-4	1118	Sodium nitrate [solid]	Chile saltpetre	✓	5.1	III	SGAV	TU3	T1	TP33
1513	10361-95-2	1121	Zinc chlorate [solid]		✓	5.1	II	SGAV	TU3	T3	TP33
1942	6484-52-2	1191	Ammonium nitrate [solid, com...		✓	5.1	III	SGAV	TU3	T1	TP33
2905	139-02-6	1200	Sodium phenolate [solid]	Phenol sodium salt	✗	8	III	SGAV		T1	TP33
2721	14721-21-2	1210	Copper chlorate [solid]	Copper (II) chlorate,...	✓	5.1	II	SGAV	TU3	T3	TP33
2723	10326-21-3	1211	Magnesium chlorate [solid]		✓	5.1	II	SGAV	TU3	T3	TP33
2725	13478-00-7	1212	Nickel nitrate [solid]	Nickel (II) nitrate, Nic...	✓	5.1	III	SGAV	TU3	T1	TP33

119 rows

Current search parameters
Tank code:
SGAV
Safety device:
not active
Vacuum valve:
Available, with opening pressure >= 0.05 bar
Thermal insulation:
not active
Tank instruction:
T6 (Land transport)
Metallic materials:
not active
Polymeric materials:
EPDM, IIR
Aggregate state:
not active
Maximum density:
not active
Maximum vapour pressure at 50 °C:
not active
Maximum vapour pressure at 65 °C:
not active
Hazard classes:
not active

Figure 3.19. Created substance lists for tanks

The current created substance list will be exported and saved as a PDF file, when you either click in the menu bar or in the tool bar "Export List as PDF..." or press the key combination "Ctrl + E". Then a dialog window opens to offer additional export settings.



Figure 3.20. PDF export dialog

In the upper area "Export to PDF" you can specify the path and file name of the PDF file. Use the button with the three dots "..." to open a file selection dialog. By default, the PDF files are stored on the desktop. The name of the generated substance list from the navigation tree is proposed as the file name. You can change the specified title (tank list, bulk container list or material resistance list) of the PDF document as well as you may specify an optional description in the underlying text box, which will appear on the first page of the PDF file.

At the lower area "Settings" you can control the PDF-output as you like. You can choose from different paper sizes, set the page orientation and determine the font size. If you check the box for "Use ratio of column widths from table", you can manipulate the column widths in the PDF output by changing the column widths in the created substance list. Check the box for "Open PDF file after export" to immediately display the exported PDF if you have installed a program that can display PDF files. All settings are automatically saved and restored when you restart the BAM List.

Click on "Export" to save the list of substances now. If the check box to show the PDF file have not been set, use the file manager of the operating system (e. g. Windows Explorer) to find the PDF file and open it. In the file your search and filter parameters are listed below the title and the optional description on the first page.



Figure 3.21. Exported PDF file with search and filter parameters

On the second page is the list of substances. The column with the names always shows the UN name in normal font and the BAM name in italics. It can happen that the UN name in land and sea transport is different. In this case, both may also be added to the BAM name.

Furthermore on each page in the header the version of the BAM List, for whom the BAM List is licensed and the corresponding license number are indicated.



Tank list (119 rows)

BAM No.	UN No.	UN Name, *BAM Name*	Class	PG	Tank code	Special provisions ch. 4.3/6.8	Tank instruction	Special provisions ch. 4.2	Conditions
104	2506	AMMONIUM HYDROGEN SULPHATE, *Ammonium hydrogen sulfate [solid]*	8	II	SGAV		T3	TP33	
256	1492	POTASSIUM PERSULPHATE, *Potassium persulfate [solid]*	5.1	III	SGAV	TU3	T1	TP33	
316	2579	PIPERAZINE, *Piperazine [anhydrous, solid]*	8	III	SGAV		T1	TP33	
532	2509	POTASSIUM HYDROGEN SULPHATE, *Potassium hydrogen sulfate [solid]*	8	II	SGAV		T3	TP33	
556	1466	FERRIC NITRATE, *Ferric nitrate nonahydrate [solid]*	5.1	III	SGAV	TU3	T1	TP33	
557	1467	GUANIDINE NITRATE, *Guanidine nitrate [solid]*	5.1	III	SGAV	TU3	T1	TP33	
635	2508	MOLYBDENUM PENTACHLORIDE, *Molybdenum pentachloride [solid]*	8	III	SGAV		T1	TP33	
763	1350	SULPHUR, *Sulfur [lump or coarse-grained powder]*	4.1	III	SGAV		T1	TP33	
653	1495	SODIUM CHLORATE, *Sodium chlorate [solid]*	5.1	II	SGAV	TU3	T3	TP33	
418	1773	FERRIC CHLORIDE, ANHYDROUS, *Ferric(III) chloride [anhydrous, solid]*	8	III	SGAV		T1	TP33	
483	2280	HEXAMETHYLENEDIAMINE, SOLID, *Hexamethylenediamine [solid]*	8	III	SGAV		T1	TP33	
494	2865	HYDROXYLAMINE SULPHATE, *Bis(hydroxylammonium) sulfate [solid]*	8	III	SGAV		T1	TP33	
1108	1452	CALCIUM CHLORATE, *Calcium chlorate [anhydrous, solid]*	5.1	II	SGAV	TU3	T3	TP33	
1113	1485	POTASSIUM CHLORATE, *Potassium chlorate [solid]*	5.1	II	SGAV	TU3	T3	TP33	
1114	1486	POTASSIUM NITRATE, *Potassium nitrate [solid]*	5.1	III	SGAV	TU3	T1	TP33	
1115	1488	POTASSIUM NITRITE, *Potassium nitrite [solid]*	5.1	II	SGAV	TU3	T3	TP33	
1117	1493	SILVER NITRATE, *Silver nitrate [solid]*	5.1	II	SGAV	TU3	T3	TP33	
1118	1498	SODIUM NITRATE, *Sodium nitrate [solid]*	5.1	III	SGAV	TU3	T1	TP33	
1121	1513	ZINC CHLORATE, *Zinc chlorate [solid]*	5.1	II	SGAV	TU3	T3	TP33	
1191	1942	AMMONIUM NITRATE [with not more than 0.2% combustible substances, including any organic substance calculated as carbon, to the exclusion of any other added substance], *Ammonium nitrate [solid, combustible substances <= 0.2 % (including any organic substance calculated as carbon, to the exclusion of any other added substance)]*	5.1	III	SGAV	TU3	T1	TP33	
1200	2905	CHLOROPHENOLATES, SOLID or PHENOLATES, SOLID, *Sodium phenolate [solid]*	8	III	SGAV		T1	TP33	
1210	2721	COPPER CHLORATE, *Copper chlorate [solid]*	5.1	II	SGAV	TU3	T3	TP33	

Figure 3.22. Exported PDF file with substance list